
Contents of the box: This Guide Power adaptor The Docking Station and plugs

USB A-B cable



1. Press the button on the power adaptor to release the plug.


7





2. Slide the existing plug out of the adaptor.

3. Slide the desired plug into the adaptor, until it clicks.

Connect the Docking Station to external power.









Note: To release the WORKABOUT PRO, press the release button down, then pull the WORKABOUT PRO up.

Allow the WORKABOUT PRO to charge for 6 hours.




Note: Full battery performance is only reached after the first few full charge/discharge cycles.

If you have a spare battery, insert it into the Docking Station to charge it.





The behaviour of the charging indicator:



Behaviour Charge Status


Off No battery in charge well or in WORKABOUT PRO,

or no external power

Solid green Battery fully charged

Fast flashing green
Slow flashing green
Solid red
Battery charged to less than 80% capacity
Battery charged to more than 80% capacity
Battery temperature outside charge range
Flashing red
Battery not charging; battery fault

6 Connect the Docking Station to the host computer.



Install ActiveSync®.

Download ActiveSync® 4.0 or higher from http://www.microsoft.com and follow the instructions to install it onto the host computer.

Configure ActiveSync.

Follow the onscreen instructions provided by ActiveSync to establish a connection between the host computer and the WORKABOUT PRO in the Docking Station.




8100125 Rev. A



Desktop Docking Station WA4003-G2

Quick Start Guide

February 20, 2007 PN: 8100125.A



ISO 9001 Certified Quality Management System

